

## INSTALLATION AND MAINTENANCE Apollo 280 (standard filtered)

**IMPORTANT:** Flushing of inlet water pipe is essential before connecting to the fountain to help prevent blockage caused by debris.

- ◆ When installing all local and state plumbing codes should be adhered to.
- ◆ Must be installed by a qualified plumber.
- ◆ Incorrect installation will affect fountain performance.
- ◆ Urban Fountains and Furniture will not be responsible for defects that arise from incorrect installation.
- ◆ All fountains are water tested prior to leaving the factory. Settings may need adjusting depending on your local water pressure.
- ◆ Component No 6 – Front Access panel - requires removing to install footings and access all internal plumbing fittings
- ◆ Component No 8 – Underside access panel - requires removing to adjust the water flow to basin nozzle (1)
- ◆ To maintain easy access over long periods of time, we recommend the use of anti-seize paste on all external bolt threads.
- ◆ All maintenance tools and replacement parts can be purchased individually from the manufacturer.
- ◆ Filters generally last 12 months (through moderate usage) before needing to be replaced. Please contact Urban for replacement filters.

### Exterior care

- ◆ Painted fountains that become dull due to prolonged exposure to direct sunlight can be restored with an appropriate surface polish.
- ◆ Regular polishing with a non-abrasive polish will help maintain the exterior of the fountain ie, Septone Fibreglass restorer and wax. To remove any Tea Staining on Stainless Steel surfaces we recommend Drifter Hull cleaner and stain remover.
- ◆ Regular washing down of the exterior surface will help prolong the lustre of the painted finish
- ◆ Do not use any solvents on the surface as this will adversely affect the longevity of the painted Finish
- ◆ Surface scratches and inconsistencies can be touched up using Dulux touch up paint. Most colours can be matched

For any advice or concerns please contact Urban Fountains and Furniture.

